

H A R B O U R

93 Litre Beverage Chiller

QUICK START GUIDE



Internal
LED Light



Triple Glazed
Tinted Door



3 x Steel
Shelves



Temp. Range
5–18° C

IN HOME WARRANTY
3
YEAR

TIPS FOR USING & OPERATING YOUR BEVERAGE CHILLER (HBRBC93B)
SUPPORT: 1300 11 4357 | WWW.HARBOUR-APPLIANCES.COM.AU

Tips & Tricks for using your new Beverage Chiller

QUICK START GUIDE: HBRBC93B

Installation & First Use

Before installing your new Beverage Chiller, please read all safety instructions in the user manual.

Place the Beverage Chiller on a sturdy, level floor for quiet operation. If it is to be placed on carpet, support it with a wooden board underneath. **This appliance is designed to be freestanding only and should not be recessed or built in.**

Before turning on your appliance for the first time:

- The beverage chiller must be rested for at least half an hour before connecting power.
- Clean the inner chamber with lukewarm water and a soft cloth.
- Do not connect cooler to electronic energy saving plug and converter that can convert DC into AC (E.g.: solar energy system, ship grid).
- Condensation or frost will form on the rear of wine cooler when the compressor is running. This is a normal function of cooler. Wiping away the frost or condensation is not required as it will eventually evaporate. The defrosted water will be collected into a drain tank and then flow into a water disposal pan above the compressor before evaporating.

Operating the Beverage Chiller

You can set and adjust the temperature in the cabinet to anywhere within the cooling range (5° C – 18° C) using the Thermostat Knob.

- “Normal”: warmest setting
- “Cold”: colder setting
- “Colder”: coldest setting

The “Off” setting turns the Beverage Chiller off. The selected setting should be pointed to the top of the dial.

For an overview and more information on your Beverage Chiller, please see pages 10–11 of your User Manual.

