


90cm Glass Gas Cooktop

QUICK START GUIDE




TIPS FOR USING & OPERATING YOUR COOKTOP (HBRCGG905W) SUPPORT: 1300 11 4357 | WWW.HARBOUR-APPLIANCES.COM.AU



Tips & Tricks for using your new Cooktop

QUICK START GUIDE: HBRCGG905W

Your 90cm Glass Gas Cooktop



How to ignite the burners

- Press in the control knob of the burner that you wish to light and turn it anti-clockwise to the Max. symbol.
- 2. If you keep the control knob depressed, the automatic ignition for the burner will operate.
- Then adjust the knob to your required temperature anywhere between the maximum and minimum symbols.
- Once you have finished using the burner ensure the knob is positioned upwards, towards the Off symbol.

Knob Controls

