

H A R B O U R

60cm 80L Electric Oven

QUICK START GUIDE



**80L Gross
Capacity**



**Triple Glazed
Door**



**Minute Minder
Timer**



**5 Oven
Functions**

IN HOME WARRANTY
3
YEAR


TIPS FOR USING & OPERATING YOUR OVEN (HBROB605)

SUPPORT: 1300 11 4357 | WWW.HARBOUR-APPLIANCES.COM.AU

Tips & Tricks for using your new Oven

QUICK START GUIDE: HBROB605

Control Panel



Oven Functions

Your Harbour 60cm 80L Electric Oven has 5 preset functions. These are:



Oven lamp



Defrost



Grill



Grill with fan



Convection

For more information on these functions refer to Page 8 of your instruction manual.

Using Your Oven

Use the timer control knob to set the oven to power off after your set number of minutes. Follow these steps to operate the oven in timer mode.

1. Rotate the timer knob clockwise to set your desired number of minutes, between 15 and 120 minutes. If you do not want to set a timer rotate the timer knob counter clockwise to the on symbol
2. Then turn the temperature knob and the function knob to your desired settings.
3. Once the timer is up the oven will make a sound to indicate that cooking is complete and the oven will automatically power off. If you didn't use a timer manually turn the oven off by turning all knobs to the upwards position.

For further operating instructions, refer to Pages 11 of your instruction manual.