


HARBOUR

12kg Top Load Washing Machine

QUICK START GUIDE



16 Wash
Programs



LED
Display



Water Level
Adjustment



Temperature
Adjustment

IN HOME WARRANTY
3
YEAR

TIPS FOR USING & OPERATING YOUR WASHING MACHINE (HBRTLWRC120W)
SUPPORT: 1300 11 4357 | WWW.HARBOUR-APPLIANCES.COM.AU



Tips & Tricks for using your new Washing Machine

QUICK START GUIDE: HBRTLWRC120W

Installation and Operation

Before installing your new Washing Machine, please read over all safety instructions in the user manual.

It is recommended to use the washing machine on its own dedicated power outlet for both convenience and safety. The power outlet must be grounded.

After loading the laundry and measuring the appropriate detergent, close the machine lid. Press the On/Off button, then turn the dial to the desired program, select any additional options and press the Start/Pause button to begin your cycle.

At the end of the cycle, the washing machine will make an audible tone. It is recommended when you are done with the machine that it should also be turned off from the power outlet and you also turn off the water supply for safety reasons.

For more further details on the installation and operation of your Washing Machine, please refer to the relevant sections of your User Manual.

Washing Programs

- NORMAL:** The standard fabric washing program.
- JEANS:** Suitable for washing all types of denim.
- MIX WASH:** Suitable for a mix load of cotton and synthetic clothing.
- WHITES:** Suitable for white clothing.
- DARK WASH:** Suitable for dark garments.
- SYNTHETIC:** Suitable to wash synthetic clothing.
- STRONG:** Increased washing time with a stronger wash stream.
- HANDWASH:** A gentle wash program.
- BABY CARE:** Suitable to wash children clothing.
- DELICATE:** A delicate wash program with a gentle water flow.
- SHEETS:** Suitable to wash sheets.
- TOWELS:** Suitable to wash towels.
- RINSE & SPIN:** An extra rinse and spin cycle.
- SOAK:** Suitable for more heavily soiled clothing.
- TUB CLEAN:** Recommended to run monthly to improve the quality of your laundry results.
- QUICK:** Suitable for washing lightly soiled laundry.

Refer to page 18 of your User Manual more details.