

HARBOUR

34 Bottle Wine Cooler

QUICK START GUIDE



Internal
LED Light



Double Glazed
Tinted Door



6 x Timber
Shelves



Temp. Range
5-18°C

IN HOME WARRANTY
3
YEAR

TIPS FOR USING & OPERATING YOUR WINE COOLER (HBRWC34B)
SUPPORT: 1300 11 4357 | WWW.HARBOUR-APPLIANCES.COM.AU



Tips & Tricks for using your new Wine Cooler

QUICK START GUIDE: HBRWC34B

Installation & First Use

Before installing your new Wine Cooler, please read all safety instructions in the user manual.

Place the wine cooler on a sturdy, level floor for quiet operation. If it is to be placed on carpet, support it with a wooden board underneath. **This appliance is designed to be freestanding only and should not be recessed or built in.**

Before turning on your wine cooler for the first time:

- The wine cooler must be rested for at least half an hour before connecting power.
- Clean the inner chamber with lukewarm water and a soft cloth.
- Do not connect cooler to electronic energy saving plug and converter that can convert DC into AC (E.g.: solar energy system, ship grid).
- Condensation or frost will form on the rear of wine cooler when the compressor is running. This is a normal function of cooler. Wiping away the frost or condensation is not required as it will eventually evaporate. The defrosted water will be collected into a drain tank and then flow into a water disposal pan above the compressor before evaporating.
- This wine cooler has a power off memory function. If the unit is powered off, the cooler will run according to previous the setting before the power off.

Operating the Wine Cooler

You can set and adjust the temperature in the cabinet to anywhere within the cooling range (5°C – 18°C) using the UP and DOWN buttons on the Control Panel to set the desired setting.

Press and hold the Lock button for 3 seconds to Unlock and Lock the Control Panel.

The light button will switch the interior light On and OFF.

Press and hold both UP and DOWN buttons simultaneously to switch between displaying the temperature in Fahrenheit or Celsius.

For more tips on operating your wine cooler, please see page 10 of your User Manual.

